


## KaiserLooper 2 Reset, Record, Play, Etc.

Reset  
Record (also overdubs)  
Play  
Direction  
Chop Mode  
Speed of playback

## Overdubbing:

Dub on/off  
Auto Dub (rhythmically overdubs/replaces at selected speed)  
Replace (sets previously recorded loop volume to 0% while overdubbing)  
Dub 100 (keeps previously recorded loop volume at 100% while overdubbing)  
Dub 50 (sets previously recorded loop volume to 50% while overdubbing)  
Dub Mix (sets previously recorded loop volume to desired level while overdubbing)  
AutoDub Speed (How fast autodub runs)  
Asynch/Synch: On Loopers 2, 3, and 4: Asynch/Synch lets each looper be independent (asynch mode) or; locked to the clock on looper A (synch mode)




## Length:

- 1) Dial in the portion of the loop you want to play
- 2) Full plays the whole loop, while maintaining A and B lengths as on the dial
- 3) A plays the portion represented on the dial
- 4) B plays the remainder of portion represented on the dial

## Chop controls:


(Work if ChopFWD or ChopRVS is selected)  
Random or URN (Unrepeating Random Numbers)  
Sliding: speed/pitch change between chopped segments  
TapTempo: Allows you to tap the tempo you want it to chop  
Segments: number of chopped segments  
ChopSpeed: How fast it chops  
SlideRange: Speed range of Sliding

## KaiserLooper 2\_



Dry input volume

Master volume



Ramp Up/Down: Adds fades at beginning and end of loop (starts at 0. ends at 1.)

Ramp Up/Down (declick)

0.001

0.999

init: resets everything

init

Pause/Play All

PausePlayAll

Asynch/Synch All (B, C, D loopers)

SynchAll

All Speed changes all looper speeds

AllSpeed

1.00